

Honeywell

Performance Series HQA DVRs



HRHH1081(X), HRHH1083(X), HRHH1161(X), HRHH1163(X), HRHH1166(X), HRHH2042(X), HRHH2082(X), HRHH2086(X),

Quick Networking Guide Document 800-19406 — Rev A — 12/2014

This guide shows how to set up your Performance Series HQA DVR for connecting to the Internet, and for using with a PC, smartphone, or tablet computer.

Before you begin, ensure that you have:

- A router and high-speed Internet access.
- The DVR is connected to a router or switch on your network using an Ethernet cable. Refer to the [Performance Series HQA DVRs Quick Installation Guide](#) for complete connection instructions.

1 Setting Up the Local Network


1. Set the network mode as either **Static** or **DHCP**.



Select the network mode.

2. Ensure that the DVR has successfully connected to the WAN.

3. To configure the DDNS settings in DDNS, go to **Main Menu > SETTING > NETWORK > DDNS**.



Set DDNS Type as **Honeywell DDNS**. Enter a custom domain name.

Click **Test** to test the connection.


2 Setting Up Router Port Mapping

Port Range					
Application	Start	End	Protocol	IP Address	Enabled
HTTP	80	to 80	Both	192.168.1. 108	<input checked="" type="checkbox"/>
TCP	37777	to 37777	Both	192.168.1. 108	<input checked="" type="checkbox"/>

1. Map the TCP port to be **37777**.
2. Map the HTTP port to be **80**.


3 Accessing the DVR Via the Web

Enter the domain name or IP address of the DVR in the address field of the Web browser.




4 Configuring the HonView Touch Mobile App

1. Install the **Honeywell HonView Touch** app



Find the free app in Apple's **App store** (iOS) or the **Google Play Store** (Android OS).


2. Tap **Device Manager**.



3. Tap **Add**, and then tap **Manually Add**.




4. Enter your user information, then click **Save**.



5. Tap to select a **Live View** channel.



6. Tap to add channels.



5 Setting Up the Tablet

1. Install, then open, the **HonView Touch HD Plus** app for free from the **App Store** or the **Google Play** store.




The **Main** window opens.

2. Tap the **Menu** icon in the **Main** window.




The **Menu** window appears.

3. Tap the **Configuration** icon in the **Menu** window.



The **Configuration** window appears.


4. Tap **Device Manager**, and then select **Add**.



The **New Device** interface appears.

5. Enter the following information in the **New Device** interface:


- **Name:** Enter a name for your DVR.
- **Address:** Enter either your DVR's DDNS address or IP address.
- **User Name:** Enter the DVR's user name (default: **admin**).
- **Password:** Enter the DVR's password (default: **1234**).



6. Tap **Save**, and then tap **Test**.

The **Main** menu returns.

7. Select a **Live View** channel.



You can now start using the DVR.

Honeywell